

V-line
THE SHAPE
of security



V-LINE BACK

SUGGESTED USE

- V-line series is the Stand anti-theft protection dedicated to smartphones and tablets.
- The aesthetic product presentation is allowed by two types of sensors: angled (25°) and flat.
- An additional advantage is the possibility of rotation of the sensor by 90°, which allows convenient testing of the product.
- Small size assured optimum visibility of the product.

WARNING!

After connecting the device to a charger, a periodically blinking yellow diode in the base indicates lack of any programmed remote controls.

The image below shows the components needed to assemble the whole system.

- 1) Stand V-line Back + V-line Back sensor
- 2) charging cable
- 3) cleaning tissue with izopropylan
- 4) USB 5V/2A power supply
- 5) smartphone

Cleaning tissue with izopropylan assures the proper preparation of the surface under Optiguard stickers.



SERIES V-LINE

Using the cleaning tissue with izopropylan, we can prepare the surface of the furniture, to which Stand V-line will be attached. After cleaning the furniture, wait until the cleaning substance evaporates.

Take off the protective papers from the stickers.



Place the cable (with USB connector) in a special groove located in the housing of Stand V-line.

Stick Stand to the furniture and press for approx. 10 seconds for good bonding of the sticker adhesive.



SERIES V-LINE

Using the cleaning tissue with izopropylan, we can prepare the surface of the mobile, to which the sensor will be attached. After cleaning, wait until the cleaning substance evaporates.



Stick the phone to the sensor and press for approx. 10 seconds for good bonding of the sticker adhesive.



Take off the protective paper from the sticker of V-line sensor.



The charging cable allows to connect the protective sensor. The smartphone will be simultaneously charged and protected.



SERIES V-LINE

Plug the end of the cable with the sticker of "ALARM" in USB of the smartphone.



Plug the other end of the cable in microUSB of V-line sensor.



USB 5V/2A charger provides adequate power for Stand V-line and allows to charge the protected product.



Plug the cable from Stand V-line with USB connector in the charger with USB port.



SERIES V-LINE

Plug USB charger with connected Stand V-line into a power outlet (AC 230V).

Powered V-line will activate within 3 seconds. Short acoustic signal and periodically blinking red LEDs in the sensor confirm activation of the system. Finished!

